

# Removing and Installing the Coin Mech



1. Undo then remove cash lock using the correct key.



2. Remove the metal cash door




3. Remove the silver locking bar and remove the plastic coin draw




4. Reach in the tower with right hand palm facing to the center of tower with index finger extended



5. Feel for small metal lever on back of coin



6. Press down the metal lever to fold in



7. You Can now remove the coin mech



8. Coin mech removed



9. To replace coin mech make sure the barrel is positioned with the hole at 11 o'clock



10. Make sure the lever is pressed down



11. Put the right side in first.



12. Release the lever.



13. Replace coin draw and locking bar



14. Replace cash door.



15. Replace and do up the cash door lock with key.



16. Test handle to make sure the coin mech is in place properly and it is turn the barrel.